

**WARNER BROS. STUDIO OPERATIONS
SAFETY & ENVIRONMENTAL AFFAIRS**



SAFETY REFERENCE MANUAL

California Code of Regulations, Title 8, Section 5157

Section 1.2: CONFINED SPACE, ENTRY FORM

Last Revised: August, 2025

PERMIT CONFINED SPACE ENTRY FORM

Date: _____ Duration of work to be conducted; From _____ : _____ to _____ : _____

Location of Work _____

Attendant / Supervisor: _____ Authorized Signature: _____

Description of Work: _____

Please fill out the following chart completely for each person that will be working in the confined space(Entrant):

NAME (FIRST, LAST)	DEPARTMENT or COMPANY
1.	
2.	
3.	
4.	
5.	
6.	

The following guidelines must be followed whenever an entrant enters an electrical vault, manhole, storm drain, sewer, sump, or other permit confined space(s):

- All workers must receive confined space training prior to entering a permit confined space.
- Workers must receive approval from their supervisor to enter a permit confined space.
- Confined space atmospheres will be monitored for oxygen (O₂), lower explosive limit (LEL), carbon monoxide (CO) and hydrogen sulfide (H₂S). Air measurements must be taken prior to the use of a ventilator fan, after the ventilator fan is used, and before any worker enters the space.
- Once it is safe to enter, air-monitoring equipment must be used to monitor the space. Periodic readings must be recorded throughout the duration of work at 30-minute intervals.
- Atmospheric levels of O₂, LEL, CO and H₂S must be within an acceptable range before workers enter or continue to work in any confined space (see chart below):
- All permit confined spaces must be ventilated continuously using a ventilator fan while workers are in the space.
- Workers must IMMEDIATELY exit any confined space if the instrument alarms, if they become dizzy, nauseous, groggy, feel ill or suspect that a condition in the space jeopardizes their health.
- One worker (**Attendant**) shall remain outside the confined space while workers are in the space. The attendant must remain in communication with all confined space workers.
- The Safety and Environmental Affairs (S&EA) department and Warner Bros. Fire Department must pre-approve any welding operations, hot work, or the use of chemicals in a confined space.
- UNDER NO CIRCUMSTANCE SHALL ANY ATTENDANT OR OTHER UNTRAINED WORKER ENTER A CONFINED SPACE TO RESCUE A DOWNED WORKER. CALL 911 IMMEDIATELY, THEN CALL 4-3333 or 818-954-3333 AS SOON AS POSSIBLE.

MONITORING RESULTS:

	Time	O ₂ (between 19.5 – 23.5%)	CO (<35 ppm)	H ₂ S (<10ppm)	%LEL (<10%)
Pre-Entry Readings (baseline)					
Readings during Operations					
Final Readings					

The completed Entry Form must be turned into the Safety Department, building 137.